


# martor


# SECUNORM GENIAL




## **USAGE**










Use the slider to **engage the blade** for cutting.


**Pierce** into the cutting material to cut.


Always remove your **thumb from the slider** to ensure automatic blade retraction.


For best results, cut plastic strapping band **diagonally** (at a 45° angle).

### **BLADE CHANGE**










Change the blade from the front side. Simply **lift** the slider and carefully remove the blade.

Either turn the blade around or replace it and re-insert **exactly over the locating lug and metal pin**.

**Fully re-close the slider** ensuring the metal pin clicks into place.


Finally, **test once** to check.


#### PROTECTION OF USER




Following cutting, the blade immediately retracts into the handle. Condition: you have **released hold of the slider**.

#### DISPOSAL







When the SAFEBOX is full, **empty all contents** into your USED BLADE CONTAINER.

**Please note:** To ensure your product always functions flawlessly, regularly remove any impurities. For additional safety, we recommend wearing gloves.