


SAFETY POSTER

INSTRUCTIONS FOR THE SAFE HANDLING OF YOUR CUTTING TOOL




SECUPRO MAXISAFE




Please note: to ensure your product always functions flawlessly, regularly remove any build-up of cutting material.


USAGE



BLADE CHANGE




PROTECTION OF USER



The blade automatically retracts into the handle the moment cutting ceases. Even when the slider is still **being held forwards**.

DISPOSAL



Your SAFEBOX is the best place to store **used blades**.

When the SAFEBOX is full, **empty all contents** into your RECYCLING BOX.